

Spare parts suitable for:
ZANUSSI





Wash and rinse systems

Page 4



Various and air traps

Page 6




Drain and filter systems

Page 8



Door and hood components

Page 11



Electrical components

Page 13



Dosing pumps

Page 19



Heating elements and boilers


Page 19




Pumps and components

Page 21

Wash and rinse systems



Item	Order	Description	Model	OEM
1	510118	rinse arm, compl.		069577
2	518328	rinse arm/ right	LTB11,	
3	518329	rinse arm/ left	LTB12,	
4	510139	rinse jet	LTB22	069451
5	510130	union nut (rinse arm)		069450




Item	Order	Description	Model	OEM
1	504500	wash arm		049044
2	504501	rinse arm		049049
3	504502	rinse arm spindle	LB1	049046
4	504503	lock nut	LB2, Z1, Z2,	049047
5	504504	wash arm bush	GW1, GW2	049042
6	504505	wash arm nut	W51, W52	049043
7	504506	nut/ wash arm support		049039
8	504507	gasket		049038



Item	Order	Description	Model	OEM
1	510135	wash jet holder/ fixed arm		069640
2	510147	wash jet	LTB11,	069641
3	518482	union nut, wash jet	LTB12,	069642
4	510112	lock screw	LTB22	069440
5	518279	cover		069444



Item	Order	Description	Model	OEM
1	510119	wash arm, compl.		069576
2	510108	rinse arm spindle	LTB11, LTB12,	069445
3	510031	wash arm support	LTB22	069443
4	518036	gasket (outlet hose)		046878




Item	Order	Description	Model	OEM
1	504508	wash arm cross		049293
2	504509	wash arm		049295
3	504510	rinse arm		049297
4	504511	rinse arm	LS5, LS32,	049298
5	504512	O-ring (rinse arm)	LS33	047473
6	504513	end cap (wash arm)		049296
7	504514	end cap (rinse arm)		049299



Item	Order	Description	Model	OEM
1	510010	wash arm cross		69452
2	518382	wash arm/ right		
3	518385	wash arm/ left		
4	518384	rinse arm/ right	LTB11,	
5	518383	rinse arm/ left	LTB12,	
6	518004	wash jet	LTB22	069449
7	510131	union nut/ wash jet		069448
8	510139	rinse jet		069451
9	510130	union nut/ rinse jet		069450




Item	Order	Description	Model	OEM
1	504515	protection (lock nut)		049294
2	504516	lock nut		047282
3	504517	nut (wash arm support)		048330
4	504537	gasket	LS5, LS32,	048236
5	504519	circlip	LS33	048979
6	504520	throttle disc		048820
7	504521	wash arm support/ lower		049290



Item	Order	Description	Model	OEM
1	504515	protection (lock nut)	LS5, LS32, LS33	049294
2	504516	lock nut		047282
3	504522	rinse arm spindle		049292
4	504512	O-ring		047473
5	504523	nut (wash arm support)		048824
6	504524	gasket		048823



Item	Order	Description	Model	OEM
1	504525	wash arm	LS6, LS7D, LS7, LS8D, LS8, LS62, LS63	048821, 048336
2	504526	rinse arm		048716, 048542
3	504527	rinse arm spindle		048290
4	504528	lock nut		048632
5	504529	wash arm bearing		048401




Item	Order	Description	Model	OEM
1	504517	nut (wash arm support)	LS6, LS7D, LS7, LS8D, LS8, LS62, LS63	048330
2	504537	gasket		048236
3	504519	circlip		048979
4	504520	throttle disc		048820
4	504530	throttle disc (L58/ old)		048645, 048931
5	504531	wash arm support/ lower		048819, 048329



Item	Order	Description	Model	OEM
1	504523	nut (wash arm support)	LS6 LS7D, LS7, LS8D, LS8	048824
2	504524	gasket		048823
3	504532	rinse arm		048333
4	504533	gasket		046366
5	504534	wash arm support/ upper		046368



Item	Order	Description	Model	OEM
1	504535	wash arm	LS10, LS12, LS14	048247
2	504526	rinse arm		048716
3	504527	rinse arm spindle		048290
4	504528	lock nut		048632
5	504529	wash arm bearing		048401



Item	Order	Description	Model	OEM
1	504536	nut (wash arm support)	LS10, LS12, LS14	048237
2	504537	gasket		048236
3	504519	circlip		048979
4	504530	throttle disc		048931
5	504539	wash arm support/ lower		048235



Item	Order	Description	Model	OEM
1	504540	wash arm	LS360, LS365	068660
2	504541	rinse arm		046371
3	504516	lock nut	LS360, LS365, LS540, LS720, LS860	047282
4	504543	rinse jet		046272
5	504544	O-ring		067898
6	504545	rinse jet holder		046273
7	504546	end cap		046266



Item	Order	Description	Model	OEM
1	504547	lock nut (wash arm)	LS360, LS365, LS540, LS720, LS860	047283
2	504548	bush (wash arm)		045771
3	504549	rinse arm spindle		046363
4	504550	wash arm bearing		046362



Item	Order	Description	Model	OEM
1	504551	wash arm support/ lower	LS360, LS365,	046373
2	504552	O-ring	LS540, LS720, LS860	027301
3	504534	wash arm support/ upper	LS360, LS365, LS540, LS720	046368
4	504554	wash arm support/ upper	LS860	046547



Item	Order	Description	Model	OEM
1	504555	nut	LS540, LS720, LS860, LS1086	047891
2	504556	O-ring		047929
3	504557	junction	LS540	047893
4	504558	junction	LS720, LS860, LS1080	047907
5	504559	gasket		047928




Item	Order	Description	Model	OEM
1	504560	wash pipe	LS360, LS365	046400
2	504561	gasket		067768
3	n. l. a.	wash pipe	LS540	046374
3	504563	wash pipe	LS720, LS860, LS1080	046544
4	504564	O-ring		065506




Item	Order	Description	Model	OEM
1	504565	wash arm cross		047990
2	504566	wash arm		047470
3	504567	rinse arm/ short		048142
4	n. l. a.	rinse arm/ long	LS510,	047889
5	504512	O-ring (rinse arm)	LS520,	047473
6	504570	end cap (rinse arm)	LS521	047475
7	504571	end cap (wash arm)		047471
8	504572	rinse jet		047927



Item	Order	Description	Model	OEM
1	504542	protection (lock nut)		047991
2	504516	lock nut	LS510,	047282
3	504573	rinse arm spindle	LS520,	047464
4	504574	O-ring	LS521	046376
5	504575	throttle disc		046361



Item	Order	Description	Model	OEM
1	504576	cover		048145
2	504577	O-ring/ inner	LS510,	047462
3	504578	O-ring/ outer	LS520,	045462
4	504579	wash arm support	LS521	047461



Item	Order	Description	Model	OEM
1	504573	rinse arm spindle		047464
2	504574	O-ring	LS510,	046376
3	504580	gasket	LS520,	046366
4	504534	wash arm support/ upper	LS521	046368

Various



Item	Order	Description	Model	OEM
1	504582	X-piece		049073
2	504583	Y-piece		048195
3	504584	Z-piece		049289




Item	Order	Description	Model	OEM
1	504585	guard filter		048746
2	504586	guard filter		048834
3	504587	non-return valve		048414



Item	Order	Description	Model	OEM
1	516101	back flow restrictor		049332
2	510789	back flow restrictor		048191

Softeners



Item	Order	Description	Model	OEM
1	504045	salt container, compl.	LB1, LB2	049075
2	510929	salt container, compl.	LTB12, LTB22	069575, 069471
3	510032	salt container, compl.		069680



Item	Order	Description	Model	OEM
1	510015	cap		069467
2	510072	gasket	LTB12, LTB22	049245, 069468
3	510018	nut		069469
4	510071	gasket		049244, 069470



Item	Order	Description	Model	OEM
1	510109	cap		069472
2	510071	gasket	LTB11	069470
3	510110	nut		069552




Item	Order	Description	Model	OEM
1	505102	softener	LB1, LB2	049074
2	530000	softener	LTB11, LTB12	069476

Detergent components




Item	Order	Description	Model	OEM
1	504690	rinse aid container		049024
2	504691	hose connector		049026
3	504692	gasket	LB1, LB2	049201, 067292
4	504693	filter		049022
5	504694	spring		049023
6	504695	flap		049021



Item	Order	Description	Model	OEM
1	510100	container, compl./ connection on the side	LTB11, LTB12, LTB22	069521
2	510099	container, compl./ connection in the front		069547



Item	Order	Description	Model	OEM
1	510077	O-ring		069644
2	510105	connection fitting	LTB11, LTB12, LTB22	069646
3	510016	banjo bolt		069645
4	510014	gasket		069525




Item	Order	Description	Model	OEM
1	504696	container		049975
2	504691	hose connector		049026
3	504692	gasket	LS5, LS32, LS33	049201, 067292
4	504693	filter		049022
5	504697	spring		048279
6	504694	spring		049023
7	504698	flap		048363

Z

Suitable for Zanussi



Item	Order	Description	Model	OEM
1	504690	container	LS6	049024
2	504699	hose connector		049941
3	504692	gasket		067292, 049292
4	504693	filter		049022
5	504697	spring		048279
6	504694	spring		049023
7	504698	flap		048363



Item	Order	Description	Model	OEM
1	504700	container	LS7	068630
2	504701	cap		068644
3	504702	suction tube		068650
4	504703	gasket		048434
5	504704	pin		068627
6	504705	spring		068645
7	504706	flap		048465




Item	Order	Description	Model	OEM
1	504707	container	LS32, LS33, LS61,	047549
2	504708	cap	LS62, LS63, LS64,	047551
3	504709	panel	LS510, LS520, LS521	047547



Item	Order	Description	Model	OEM
1	504710	nut	LS32, LS33, LS61, LS62, LS63, LS64, LS510, LS520, LS521	047550
2	504711	gasket		030186
3	504712	funnel		047548
4	504713	suction tube		047552

Air traps



Item	Order	Description	Model	OEM
1	504617	air trap (drain pump)	LB1, LB2, LS5, LS6,	048853
2	504618	gasket	LS7, LS8, LS10,	068642
3	504619	hose clamp	LS12, LS14, LS33, LS63, LS64	046946



Item	Order	Description	Model	OEM
1	510103	air trap, compl.	LTB11, LTB12, LTB22	069515
2	510077	O-ring		069644
3	510105	connection for pump		069670
4	510017	union nut		0A6065
5	510016	banjo bolt		069646




Item	Order	Description	Model	OEM
1	504620	air trap	LS5, LS6, LS7, LS8, LS10,	048308
2	504618	gasket	LS12, LS14, LS32, LS33,	068642
3	504621	nut	LS61 - LS64	049268
4	504622	air trap	LS10 (old), LS12 (old), LS360,	046631
5	504623	O-ring	LS365, LS510, LS520, LS521	068573
6	504624	air trap	LS540, LS720, LS860, LS1080	045459
7	504623	shaft seal		068573


Drain and filter systems



Item	Order	Description	Model	OEM
1	504588	drain plug	LB1, LB2	049914
2	504589	drain plug, drain pump		049915
3	504590	O-ring		049036



Item	Order	Description	Model	OEM
1	504591	filter	LB1, LB2	049032
2	504592	nut		049034
3	504593	O-ring		049033
4	504594	drain unit with air trap		049035



Item	Order	Description	Model	OEM
1	504595	filter	LS5, LS6, LS7, LS8, LS32, LS33, LS62, LS63	048324
2	504596	nut		048326
3	504597	gasket		048327
4	504598	sump		048325




Item	Order	Description	Model	OEM
1	510038	drain plug	LTB11, LTB12, LTB22	069526
2	518490	drain plug (drain pump)		069527
3	518491	O-ring		069527
4	510045	sump/filter compl.		069574




Item	Order	Description	Model	OEM
1	504599	drain plug	LS10, LS12, LS14	048250
2	504600	gasket		048229
3	504601	inlet body		049600



Item	Order	Description	Model	OEM
1	510040	outer filter	LTB11, LTB12, LTB22	069528
2	510041	inner filter		069529



Item	Order	Description	Model	OEM
1	510433	drain plug + filter	LS360	068713
2	n. l. a.	drain plug	LS365	046635
3	504578	O-ring	LS360, LS365	045462
4	504604	inlet body		046396, 046395



Item	Order	Description	Model	OEM
1	518199	filter location	LTB11, LTB12, LTB22	069530
2	510009	O-ring		069531
3	518201	inlet body		069532




Item	Order	Description	Model	OEM
1	510434	drain plug + filter	LS540, LS720, LS860, LS1080	045476
2	504578	O-ring		045462
3	504605	inlet body	LS540, LS720	045458
4	504606	inlet body	LS860, LS1080	046525



Item	Order	Description	Model	OEM
1	510770	drain plug	LS5, LS6, LS7, LS8, LS32, LS33, LS62, LS63	048323
2	510771	drain plug (drain pump)		048842
3	510769	gasket		046799



Item	Order	Description	Model	OEM
1	510768	drain plug	LS510, LS520	047460
2	504607	drain plug	LS521	047556
3	510769	O-ring		046799



Item	Order	Description	Model	OEM
1	504608	filter		047456
2	504609	O-ring	LS510, LS520, LS521	047458
3	504610	inlet body		047457

Flat filters



Item	Order	Description	Model	OEM
1	504611	flat filter	LB1, LB2	049051
2	504612	flat filter	LS6	049908
3	504613	flat filter	LS10, LS12, LS14	048252



Item	Order	Description	Model	OEM
1	504614	flat filter	LS7, LS8, LS32, LS33, LS61 - 64	048332
2	504615	flat filter	LS510, LS520, LS521	047544



Item	Order	Description	Model	OEM
1	504616	drain seating	LS10, LS12, LS14	049633

Hoses



Item	Order	Description	Model	OEM
1	504625	inlet hose	LB1, LB2	049041
2	518217	inlet hose	LTB11, LTB12, LTB22	069537
3	518216	outlet hose		046878




Item	Order	Description	Model	OEM
1	504626	inlet hose	LS5, LS6, LS7, LS8, LS32, LS33, LS61 - LS64	045768
2	504627	outlet hose		046257



Item	Order	Description	Model	OEM
1	504628	inlet hose	LS360, LS365, LS510, LS520, LS521	045457
2	504629	outlet hose	LS360, LS365, LS510, LS520, LS521	046398
3	504627	outlet hose		046257



Item	Order	Description	Model	OEM
1	504628	inlet hose		048242
2	504629	outlet hose		045456
3	504626	inlet hose	LS10, LS12, LS14	045768
4	504630	outlet hose (old)		048241



Item	Order	Description	Model	OEM
1	504631	inlet hose		045456
2	504632	outlet hose	LS540, LS541,	046372
3	504627	outlet hose	LS720, LS721	046257




Item	Order	Description	Model	OEM
1	504641	hinge/ left		049280
2	504640	hinge/ right		049279
3	504642	hinge pin		049281
4	504643	door stay		049282
5	504644	end stop		049286
6	504645	rod guide		049285




Item	Order	Description	Model	OEM
1	504633	inlet hose		046565
2	504634	outlet hose	LS860, LS861,	046542
3	504635	outlet hose	LS1080	046546


Door components



Item	Order	Description	Model	OEM
1	504636	plastic plate	LB1, LB2	049246
2	504637	spring jack		049030
3	504638	spring	LB1	049200
4	504639	spring	LB2	049086



Item	Order	Description	Model	OEM
1	504646	hinge lever/ right		048813
2	504647	hinge lever/ left	LS6, LS61, LS62,	048814
3	504648	bush	LS63, LS64	048812
4	504649	spring		048815



Item	Order	Description	Model	OEM
1	504650	hinge/ right		048583
2	504651	hinge/ left		048582
3	504652	spring right	LS7	046269
4	504653	spring left		046268
5	504654	spring linkage		048581



Item	Order	Description	Model	OEM
1	504655	hinge/ right		046292
2	504656	hinge/ left		046291
3	504652	spring right	LS360, LS365,	046269
4	504653	spring left	LS540, LS541	046268
5	504654	spring linkage		048581, 046267



Item	Order	Description	Model	OEM
1	518546	hinge/ right		069513
2	518547	hinge/ left	LTB11, LTB12,	
3	518256	hinge clamp/ right	LTB22	069514
4	518257	hinge clamp/ left		

Z




Item	Order	Description	Model	OEM
1	504657	hinge	LS510, LS520, LS521	048161
2	504658	hinge screw		047478
3	504659	catch housing		047491
4	504660	spring		047492
5	504661	door catch		047493




Item	Order	Description	Model	OEM
1	510068	catch	LTB11, LTB12,	069435
2	510069	door catch	LTB22	069436
3	504662	catch	LS5, LS32,	049271
4	504663	door catch	LS33	049536



Item	Order	Description	Model	OEM
1	504664	door frame	LS360, LS365	046392
2	504665	door frame	LS510, LS520, LS521	047483
3	504666	door frame	LS540	046270



Item	Order	Description	Model	OEM
1	504667	door seal/ upper	LB1, LB2	049017
2	504668	door seal/ lower		049016
3	504669	door seal/ upper	LS5, LS32, LS33	046583
4	504670	door seal/ upper	LS6	049932



Item	Order	Description	Model	OEM
1	504671	door seal/ upper	LS7	049248
2	504672	door seal/ upper	LS61 - LS64	048306
3	504673	door seal/ upper	LS360, LS365	046394



Item	Order	Description	Model	OEM
1	504674	door seal/ right	LS510, LS520, LS521	047454
2	504675	door seal/ left		047455

Hood components




Item	Order	Description	Model	OEM
1	504676	handle support	LS720, LS860, LS1080	046537
2	504677	bush		046538
3	504678	handle support	LS12 (old)	049430
4	504679	screw		048349




Item	Order	Description	Model	OEM
1	504680	handle support	LS12, LS14	049597
2	504681	roller		049598



Item	Order	Description	Model	OEM
1	504682	spring	LS720	046615
2	504683	spring	LS860, LS1080	046540
3	504684	spring	LS8	048655




Item	Order	Description	Model	OEM
1	504685	spring	LS10, LS12, LS14	049582
2	504686	spring	LS10 (old), LS12 (old)	048258
3	504687	spring	LS14EA/ AU	049947




Item	Order	Description	Model	OEM
1	504688	spring compressor	LS720, LS860, LS1080, LS8, L10 (old), LS12 (old)	075767
2	504689	spring compressor	LS10, LS12, LS14	049583


Electrical components




Item	Order	Description	Model	OEM
1	400915	fascia	LS5	049956
2	400916	display p.c.b.		0L0047
3	400917	main p.c.b.		0L0046




Item	Order	Description	Model	OEM
1	400918	fascia	LS6	049920
2	400919	display p.c.b.		049897
3	400920	main p.c.b.		049910, 0L0045



Item	Order	Description	Model	OEM
1	400921	fascia	LS10EA	0L0008
2	400922	fascia	LS14EA	0L0001
3	400923	display p.c.b.	LS10EA,	049998
4	400920	main p.c.b.	LS14EA	0L0045
4	400961	main p.c.b.		0L0541




Item	Order	Description	Model	OEM
1	400924	fascia	LS10	049605
2	400925	fascia	LS12	049606
3	400926	fascia	LS12AU	049604




Item	Order	Description	Model	OEM
1	400927	display p.c.b.	LS10, LS12	049623, 049754
2	400920	main p.c.b.		049622, 049752, 0L0045



Item	Order	Description	Model	OEM
1	400928	main p.c.b.	LS61, LS62	048833
2	400929	main p.c.b.	LS63, LS64	048926



Item	Order	Description	Model	OEM
1	400930	main p.c.b.	LS8DP	049150
2	400931	main p.c.b.	LS10DP	049141
3	400932	main p.c.b.	LS12DP	049147



no picture!
2

Item	Order	Description	Model	OEM
1	360275	timer p.c.b.	LS32	049411
2	360276	timer p.c.b.	LS33	049412




Item	Order	Description	Model	OEM
1	379901	sensor	LS5, LS6	049884
2	379902	sensor	LS5, LS6,	049643
3	504574	gasket	LS10, LS12,	046376
4	504753	holder	LS14	049580

Fasciae



Item	Order	Description	Model	OEM
1	504714	fascia	LB1, LB2	049061
2	504715	fascia	LS7	048339
3	504716	fascia	LS32, LS33	049313



Item	Order	Description	Model	OEM
1	504717	fascia	LS61, LS62	048827
2	504718	fascia	LS63	048903
3	504719	fascia	LS520	047545 047633




Item	Order	Description	Model	OEM
1	504720	fascia	LS521	047561 047633
2	504721	fascia	LS540, LS720	046345
3	504722	fascia	LS860	046732




Item	Order	Description	Model	OEM
1	504723	fascia	LS8	048648
2	504724	fascia	LS8DP	049151
3	504725	fascia	LS10	048470




Item	Order	Description	Model	OEM
1	504726	fascia	LS10	048590
2	504727	fascia	LS10DP	049143
3	504728	fascia	LS12	048473




Item	Order	Description	Model	OEM
1	504729	switch panel	LS12DP	049148
2	504730	switch panel	LS12HD	048598
3	504731	gasket	universal	048274




Item	Order	Description	Model	OEM
1	345831	switch	LB1, LB2	049063
2	345832	push button		049068
3	345833	push button		049062
4	345834	push button		049065
5	345836	signal lamp		049064



Item	Order	Description	Model	OEM
1	345005	switch combination	LTB11	069412
2	345006	switch combination	LTB12, LTB22	069413



Item	Order	Description	Model	OEM
1	359001	signal lamp	LTB11, LTB12, LTB22	069415
2	359002	signal lamp	LTB22	069416
3	359003	signal lamp		069418
4	359006	signal lamp	LTB12, LTB22	069417




Item	Order	Description	Model	OEM
1	345824	switch	LS32, LS33	049316
2	345825	push button		049315
3	345826	switch	LS33	049326




Item	Order	Description	Model	OEM
1	345827	push button/ grey	LS32, LS33	049317
2	345828	push button/ yellow		049318
3	345829	push button	LS33	049325
4	345830	blind cap	LS32, LS33	049314



Item	Order	Description	Model	OEM
1	359130	signal element/green		048832
2	359126	socket/green		075096



Item	Order	Description	Model	OEM
1	345169	main switch		048829
2	345168	program switch		048828
3	504732	gasket	LS61, LS62,	046360
4	110907	knob	LS63, LS64	048830
5	504733	grub screw		047846
6	359130	signal element		048832
7	359126	socket/ green		075096




Item	Order	Description	Model	OEM
1	301087	rotary switch		047498
2	301180	rotary switch		047560
3	504732	gasket	LS510, LS520,	046360
4	110910	knob	LS521	047842
5	504733	grub screw		047846



Item	Order	Description	Model	OEM
1	301181	rotary switch	LS360	047360
2	301182	rotary switch	LS365	046649
3	504732	gasket		046360
4	110911	knob	LS360, LS365	046356 Z
5	504734	grub screw		046258




Item	Order	Description	Model	OEM
1	359130	signal element, 230V		046241
1	359132	signal element/ green, 230 V		046076
2	359127	socket/ yellow	LS360, L365,	075095
3	359126	socket/ green	LS510, LS520,	075096
4	359792	socket/ blue	LS521	047750
5	359225	socket/ clear		046289




Item	Order	Description	Model	OEM
1	301183	rotary switch		046350
2	504732	gasket	LS540, LS541,	046360
3	110911	knob	LS720, LS860,	046356
4	504733	grub screw	LS1080	047846



Item	Order	Description	Model	OEM
1	359130	signal element		048832
1	359132	signal element/ green, 230V	LS540, LS541,	046076
2	359225	socket/ clear	LS720, LS860,	046289
3	359126	socket/ green	LS1080	075096
4	359792	socket/ blue		047750



Item	Order	Description	Model	OEM
1	345021	switch	LS540, LS541,	045165, 046348
2	504735	gasket	LS720, LS860,	046298
3	345744	push button	LS1080,	046293
			LS360, LS365	



Item	Order	Description	Model	OEM
1	345171	main switch	LS7, LS10 (to Nr 304_), LS12 (to Nr 304_)	048271
2	345172	main switch	LS8, LS10 (from Nr 305_), LS12 (from Nr 305_)	048524
3	345170	program switch	LS7, LS8, LS10	048270



Item	Order	Description	Model	OEM
1	301184	program switch	LS12	048286
2	301185	main switch	LS7DP	048828
3	301186	main switch	LS8DP, LS10DP, LS12DP	049144
4	301187	program switch	LS7DP, LS8DP, LS10DP, LS12DP	049145




Item	Order	Description	Model	OEM
1	504732	gasket		046360
2	110912	knob	LS7	048340
3	110913	knob	LS8, LS10, LS12	048402
4	504733	grub screw		047846




Item	Order	Description	Model	OEM
1	359130	signal element, 230 V	LS7, LS8 LS10, LS12	048488
1	359132	signal element/green, 230 V		048832
2	359126	socket/green		075096


Timers




Item	Order	Description	Model	OEM
1	360279	120"/ 300", 7 cams, 230 V	LB1, LB2 (to Nr 716)	49054
2	360278	120"/ 300", 7 cams, 230 V	LB1 (from Nr 717), LB2 (from Nr 717)	49256
3	360277	regeneration, 230 V	LB1, LB2	49251



Item	Order	Description	Model	OEM
1	360024	120", 230 V	LTB11, LTB12, LTB22	069419, 069669
2	360005	20", 230 V (regeneration)		069420



Item	Order	Description	Model	OEM
1	360283	230 V	LS360, LS365	068671
2	360039	180", 4 cams, 230 V	LS510, LS520, LS521	047497, 048881



Item	Order	Description	Model	OEM
1	360280	230 V	LS720	046621
2	360281	230 V	LS860	046733



Item	Order	Description	Model	OEM
1	360071	5 cams, 230 V	LS7	48303
2	360073	5 cams, 230 V	LS8	48647
3	360074	6 cams, 230 V	LS10, LS12	48591, 48264

Pressure switches



Item	Order	Description	Model	OEM
1	541177	110/ 55, 165/ 135 (drain pump)	LB1, LB2	049081
2	541171	110/ 55		049058
3	541003	55/ 35	LTB11, LTB12, LTB22	069434




Item	Order	Description	Model	OEM
1	541006	60/ 20	LS360, LS510, LS520, LS540, LS7, LS8	049485, 046352, 048723
2	541007	68/ 54	LS365	046648
3	541172	110/ 85 - 60/ 20	LS521	048752




Item	Order	Description	Model	OEM
1	541008	105/ 60	LS720, LS860, LS1080	046601
2	541173	2 levels	LS7DP, LS8DP, LS61, LS62, LS63, LS64	048826
3	541178	250/ 130 - 390	LS10, LS12, LS12DP, LS14 (electronic control)	049620




Item	Order	Description	Model	OEM
1	541179	240/ 130	LS10, LS12	048267
2	541174	2 levels	LS10DP, LS12DP	049142




Item	Order	Description	Model	OEM
1	541175	60/ 20	LS32	049305, 049881
2	541176	110/ 80 - 60/ 20	LS32 (from Nr 731_), LS33 (from Nr 731_)	049361




Item	Order	Description	Model	OEM
1	390004	30 - 90 °C (boiler)	LTB11, LTB12,	069422
2	390005	0 - 85 °C (tank)	LTB22	069423



Item	Order	Description	Model	OEM
1	375210	30 - 90 °C (boiler)	LB1, LB2	049191
2	390467	82 °C fixed (boiler)	LS32, LS33	049255



Item	Order	Description	Model	OEM
1	390038	30 - 90 °C (boiler)	LS360, LS365	045169
2	375061	30 - 90 °C (boiler)	LS360, LS365D	46413



Item	Order	Description	Model	OEM
1	390030	30 - 90 °C (boiler)	LS7, LS8, LS10, LS12, LS540, LS720, LS860, LS1080, LS61 - LS64	048266, 068012, 049243
2	390165	safety thermostat, 140 °C (boiler)	LS520D, LS521D, LS540, LS720, LS860, LS1080	051644


Thermostats



Item	Order	Description	Model	OEM
1	390101	contact thermostat	LS360, LS365, LS510, LS520, LS521, LS540, LS720, LS860, LS1080, LS7, LS8, LS10, LS12	045495, 048487, 047508
2	390466	contact thermostat	LS510, LS520, LS521	048166, 048631




Item	Order	Description	Model	OEM
1	390468	contact thermostat (tank)	LS - DP, LB1, LB2, LS32, LS33, LS61 - LS64	48804
2	390138	safety thermostat, 112 °C (boiler)	LB1, LB2, LS32, LS33, LS61 - LS64, LS7, LS8,	048887, 048287
3	504736	support plate	LS10, LS12	048987



Item	Order	Description	Model	OEM
1	504544	O-ring	universal	067898
2	504738	screw		067899
3	510417	gasket		
4	521134	nut, M14 x 1		

Micro switches




Item	Order	Description	Model	OEM
1	345257	micro switch	LTB11, LTB12, LTB22	069484
2	345254	micro switch	LS360, LS365, LS510, LS520, LS521, LS540	047485, 046286, 046379
3	345815	micro switch	LS720, LS860, LS1080	060722



Item	Order	Description	Model	OEM
1	345816	magnetic switch	LB1, LB2, LS8, LS10, LS12	048486
2	345117	magnetic switch	LS7 (to 1994)	048392
3	345818	magnetic switch	LS7 (from 1994)	048893




Item	Order	Description	Model	OEM
1	345819	magnetic switch	LS7DP, LS8DP, LS10DP, LS12DP, LS61, LS62, LS63, LS64	048831
2	345820	magnetic switch	LS32, LS33	049226
3	345821	electronic control	LS5, LS6, LS10, LS12, LS14, LS10DP	049621




Item	Order	Description	Model	OEM
1	345822	magnetic switch/level regulator	LS8, LS10, LS12	049478
2	345823	limit switch	LS720, LS860, LS1080	048159


Solenoid valves



Item	Order	Description	Model	OEM
1	370019	double, 230 V	LB1, LB2	049056
2	370023	triple, 230 V		049077




Item	Order	Description	Model	OEM
1	370021	double, 230 V	LTB11	069463
2	370025	triple, 230 V	LTB12, LTB22	069464



Item	Order	Description	Model	OEM
1	370016	single, 230 V	LS7, LS8, LS10, LS12, LS510, LS520, LS521, LS540, LS720, LS860, LS1080, LS5, LS61 - LS64	047529, 048178, 047843, 046320, 048898, 048817, 048894
2	370022	double, 230 V	LS_HD	049230


Relays



Item	Order	Description	Model	OEM
1	380183	2 changeover, 12 A (AC1)	LB1, LB2, LS7, LS10 (to Nr 304_), LS12 (to Nr 304_)	48438
2	380196	4 changeover, 12 A (AC1)	LB1, LB2, LS10 (from Nr 305_), LS12 (from Nr 305)	48611
3	380131	3 changeover, 16 A (AC1)	LS360, LS365, LS540, LS720, LS860, LS1080	046380



Item	Order	Description	Model	OEM
1	380318	2 NO, 16A (AC1)	LS7DP, LS8DP, LS10DP, LS12DP, LS32, LS33, LS61 - LS64	048888
2	380622	time relay, 0,05 sec - 60 h (multifunction)	LS_HD	049235
3	380136	base		049236



Item	Order	Description	Model	OEM
1	380203	3 NO/ 1 NC, 230 V	LS7, LS8, LS10, LS12, LS14, LS32/4,5, LS33/4,5, LS61 - LS64	048403, 048825
2	380204	230 V	LS540, LS720, LS860, LS1080	075796, 082986

Dosing pumps



Item	Order	Type	Model	OEM
1	361370	Glados, diaphragm	LB1, LB2, LS5, LS32, LS33, LS7 (from Nr 545_), LS8 (from Nr 545_), LS10 (from Nr 242_), LS12 (from Nr 242_)	048715, 049484
2	361008	Lang, diaphragm	LS10 (to Nr 241_), LS12 (to Nr 241_9, LS360, LS365, LS510, LS520, LS521, LS540, LS720, LS860, LS1080	048498, 045478



Item	Order	Type	Model	OEM
1	361004	DB2, 230 V (electrical)	LTB11, LTB12, LTB22	069478, 069921
2	361113	solenoid coil, DB2		049625
3	361013	Lang, 230 V (electrical)		048580



Item	Order	Typ	Model	OEM
1	361152	detergent (dosing pump)	LS6, LS10, LS12, LS14 (electronic control)	049624
2	361150	rinse aid (dosing pump) 0,4 l		
2	361151	rinse aid (dosing pump) 1,5 l		049625




Item	Order	Description	Model	OEM
1	361141	bottle weight/filter		049356
2	361270	chemical feed elbow		049557
3	361147	non-return valve		




Item	Order	Description	Model	OEM
1	361134	hose (detergent)		049149
2	361135	hose (rinse aid)		049148

Heating elements

Tank heating elements



Item	Order	Description	Model	OEM
1	415010	2000 W, 230 V	LTB11, LTB12, LTB22	069437, 069671
2	415272	800 W, 230 V	LB1, LB2	049059
3	415070	2200 W, 230 V	LS6, LS7, LS8, LS10, LS12, LS32, LS33, LS61 - LS64	048228, 048924
3	416133	2000 W, 230 V	LS5	049954




Item	Order	Description	Model	OEM
1	416132	3000W, 230V	LS10EA, LS14	048491
2	415072	2200W, 230V	LS360, LS365, LS520D, LS521D, LS720, LS860, LS1080	046404, 046418, 048000, 048086
3	415073	2200W, 230V	LS510, LS520, LS521, LS540	046284, 047507, 047848, 047506

Tank heating elements/ Accessories



Item	Order	Description	Model	OEM
1	510416	gasket		069438
2	520231	nut, M10 x 1		
3	521132	O-ring	universal	046223
4	521133	nut, M14 x 1		046223
5	510387	gasket		
6	510388	flange		048483

Boiler elements



Item	Order	Description	Model	OEM
1	415002	3000W, 230V	LTB11, LTB12, LTB22	069455, 069672
2	415174	3000W, 3 phases 230V	LB1, LB2, LS62 - LS64	048927
3	416130	2800W, 230V	LS32, LS33	049371



Item	Order	Description	Model	OEM
1	416135	2800W, 230V	LS5	049980
2	416128	4500W, 3 phases 230V	LS5	049955
3	415067	4500W, 3 phases 230V	LS7/ 9, LS8/ 9, LS12	048928, 048284



Item	Order	Description	Model	OEM
1	415068	6000W, 3 phases 230V	LS7, LS8, LS10	048513, 048221
2	416129	6000W, 3 phases 230V	LS6	048898
3	416131	4500W, 3 phases 230V	LS32, LS33, LS540D, LS720D, LS860D	049307, 052905, 026453



Item	Order	Description	Model	OEM
1	415066	4500W, 230V	LS520D, LS521D	047847
2	415080	6000W, 230V		
3	416134	10500W, 230V	LS10EA, LS14	049997




Item	Order	Description	Model	OEM
1	415597	3000W, 3 phases 230V	LS510, LS520, LS521	066109, 047505
2	415069	4500W, 3 phases 230V	LS360, LS720, LS860	065557, 045518, 046623, 046627
3	415379	6000W, 3 phases 230V	LS1080	051632, 066110



Item	Order	Description	Model	OEM
1	510408	O-ring		003362
2	520236	flange		065558

Boilers


Item	Order	Description	Model	OEM
1	504739	boiler	LB1, LN2	049053
2	504740	boiler	LTB11, LTB12, LTB22	069453
3	504741	boiler	LS360, LS365	046294



Item	Order	Description	Model	OEM
1	504742	boiler	LS510, LS520, LS521	048194
2	504743	boiler	LS540	048197
3	504744	boiler	LS720, LS860, LS1080	047950



Item	Order	Description	Model	OEM
1	504745	boiler	LS32, LS33	049336
2	504746	boiler	LS61, LS6EP, LS7, LS8, LS10	048548, 048341
3	504747	boiler	LS62, LS63, LS64, LS7/ 9, LS8/ 9, LS12	048484, 048727




Item	Order	Description	Model	OEM
1	504748	boiler	LS5	049958
2	504749	boiler	LS6	049902



Item	Order	Description	Model	OEM
1	504750	boiler	LS10EH, LS14	049987
2	504751	boiler	LS10, LS12 (electronic control)	049632

Pumps

Drain pumps



Item	Order	Description	Model	OEM
1	500392	34W, 230V	LB1, LB2, LS33, LS63, LS64, LS6_DP, LS7DP, LS8DP, LS10DP, LS12DP	048844
2	500207	90W, 230V	LS365	046647
3	500206	90W, 230V	LS521	047562

Booster pumps



Item	Order	Description	Model	OEM
1	500393	350W, 230V	LB1, LB2, LS32, LS33, LS62HD	048910
2	500394	280W, 230V	LS6EA, LS10/ LS12/ LS14 - (electronic control)	049310
3	500395	350W, 230V	LS8HD, LS10HD, LS12HD	049229

Wash pumps



Item	Order	Description	Model	OEM
1	500129	280W, 230V	LB1, LB2	049057
2	500003	290W, 230V	LTB11, LTB12, LTB22	069450, 069804, 069675, 069805
3	500114	740W, 230V	LS32, LS33, LS61 - LS64, LS7DP, LS8DP	048885




Item	Order	Description	Model	OEM
1	500090	550W, 230V	LS360, LS365, LS510, LS520, LS521	046370
2	500396	750W, 230V	LS5, LS6	049876
3	500113	740W, 230V (3 ph)	LS7, LS8	048304



Item	Order	Description	Model	OEM
1	500397	1kW, 400V, (3 ph)	LS860, LS1080	047708
2	500115	1,5 kW, 400V, (3 ph)	LS10, LS12, LS14	048216



Item	Order	Description	Model	OEM
1	500112	550W, 230V	LS540D	046574
2	500056	550W, 400V (3 ph)	LS540D, LS720	046346



Pumps		1 Impellor		2 Mechanical seal		3 Housing gasket		4 Pump cover		5 Capacitor	
Order	OEM	Order	OEM	Order	OEM	Order	OEM	Order	OEM	Order	OEM
500003	069804	510615	69545	510693	69543	510554	69544	510512	-	365013	69541
500056	046346	510601		510693		510551		510502		--	
500090	046370	521237		510692		521709		521531		365014	
500112	046574	510601		510693		510551		510502		--	
500113	048304	521271		510692		521709		521531			
500114	048885	509021		510692		521709		521531		365021	
500115	048216	510602		510693		510551		521515		--	
500129	049057	521227		510692		521705		521522		365012	
500394	049310	521206		510695		509002		510384		365012	
500396	049876	521208		510692		521702		521506		365021	
500397	047708	521216		510693		510551		521514	48059	--	