

HOME LAUNDRY AND DISHWASHERS


PUMPS COMPLETE, PARTS

4812 360 18004

DRAIN PUMP

Suitable For:
WHIRLPOOL DISHWASHER -
ADG635W

ORIGINAL PART



G126

DRAIN PUMP

Suitable For:
AEG DISHWASHER - FAVORIT
SERIES (MOST MODELS)

OEM REF: 6460855530




4812 360 18022

DRAIN PUMP

Suitable For:
WHIRLPOOL DISHWASHER -
ADP256, ADP556, ADP566,
ADP751

ORIGINAL PART



A114

DRAIN PUMP

Suitable For:
INDESIT DISHWASHER -
D4000WZ, DG5000, DG5100

OEM REF: 044712




4812 360 18357

DRAIN PUMP

Suitable For:
WHIRLPOOL DISHWASHER -
ADP952

ORIGINAL PART



4819 360 18217

DRAIN PUMP

Suitable For:
KIC DISHWASHER - D4800,
D5000, AFL - W600K

ALT NO: EC107



DY76

DRAIN PUMP

Suitable For:
DEFY DISHWASHER -
DISHMAID: MKI, MKII, MKIII, A, B,
C, 3126, 3127, 3128

