

HOME LAUNDRY AND DISHWASHERS

SWITCHES DOOR, TEMPERATURE, MAINS

953820

ORIGINAL PART

DOOR MICRO SWITCH

Suitable For:

HOOVER TUMBLE DRYER -
D6148, D6200, D6202, D6208,
D6296, D6298, D6430, D6500,
D6502, D6504, D6628, D6888,
D6890, D6938, D6980, D6983,




DY51

DOOR MICRO SWITCH

OEM REF: 9720036

Suitable For:

DEFY TUMBLE DRYER -
AUTODRIER 3.6, AUTODRY 36,
AUTODRY 45, SENSIMATIC 45,
VARIDRY



DY47

OEM REF: 9720172

TWO HEAT ROTARY SWITCH

Suitable For:

DEFY TUMBLE DRYER -
AUTODRY 36, AUTODRY 45



E108

START SWITCH

OEM REF: AD860286

Suitable For:

KELVINATOR TUMBLE DRYER -
N130, N140; GENERAL ELECTRIC
TUMBLE DRYER - DE7



DY48

OEM REF: 9720037

BELT BRAKE SWITCH

Suitable For:

DEFY TUMBLE DRYER -
AUTODRIER 3.6, AUTODRY 36,
AUTODRY 45, SENSIMATIC 45,
VARIDRY



E116

TWO HEAT ROCKER SWITCH

OEM REF: AD860283

Suitable For:

KELVINATOR TUMBLE DRYER -
N130, N140; GENERAL ELECTRIC
TUMBLE DRYER - DE7




DY50

OEM REF: 9720601

MOTOR MICRO SWITCH

Suitable For:

DEFY TUMBLE DRYER -
AUTODRIER 3.6, AUTODRY 36,
AUTODRY 45, SENSIMATIC 45,
VARIDRY




PBS2

**UNIVERSAL TWO WAY PUSH
BUTTON SWITCH**

INDESIT OEM REF: MEA015FA

Suitable For:

DEFY T/DRYER - AUTODRY 5:
D150, 'DTD' SERIES; INDESIT
DISHWASHER - 115, 116, 2115,
2116; INDESIT AFL - W400, W410,
W411, W420, W421, W600F;



PN-AD55882

START SWITCH

Suitable For:

SPEEDQUEEN TUMBLE DRYER -
HE4930, NE5313

ORIGINAL PART



4812 278 18003

ON/OFF SWITCH

Suitable For:

WHIRLPOOL TUMBLE DRYER -
AWZ121

ORIGINAL PART

